

User Manual

Navigation Software

Table of Contents

1 Starting up	4
1.1 Important information	5
1.2 Alternative installation of navigation software from a memory card	5
1.3 Further map material	5
1.4 Transferring map material to a memory card	6
1.5 Transferring installation files and map material to the internal memory	6
1.6 Data transfer (GoPal Assistant)	7
 2 Operating the navigation software	 8
2.1 Symbols	9
2.2 Map	10
2.3 Destination	12
2.3.1 Enter new destination	12
2.3.2 Search for	13
2.3.3 Favourites	13
2.3.4 Last locations	13
2.3.5 Route options	14
2.3.6 Add location to favourites	14
2.3.7 Show location	14
2.3.8 Calculating the route	15
2.3.9 Quick search	15
2.3.10 Area search	15
2.3.11 Route planning	15
2.3.12 Save current position	16
2.3.13 Stored locations	16
2.4 Route	16
2.4.1 Go to	16
2.4.2 Change route	16
2.4.3 Directions	16
2.4.4 Route options	16
2.4.5 Stop route guide	16
2.5 View	17
2.5.1 2-D or 3-D map	17
2.5.2 Turn icon view	17
2.5.3 Traffic Situation	18
2.5.4 Compass	18
2.5.5 Journey info	19
2.5.6 Other Applications	19
2.6 Settings	19
2.6.1 Settings for the unit	19
2.6.2 Display	20
2.6.3 Volume control	20

2.6.4 Language	20
2.6.5 Map selection	20
2.6.6 Advarsel om max. hastighed	20
2.6.7 Search for TMC stations.	21
2.6.8 TMCpro search	21
2.6.9 Congestion by-pass	21
2.6.10 Preferred petrol stations	21
2.6.11 Quick search category	22
2.6.12 Info	22
3 Further notes	23
3.1 Liability	24
3.2 Trademarks	24

1. Starting up

This chapter contains information about the following subjects:

- 1.1 Important information
 - 1.2 Alternative installation of navigation software from a memory card
 - 1.3 Further map material
 - 1.4 Transferring map material to a memory card
 - 1.5 Transferring installation files and map material to the internal memory
 - 1.6 Data transfer (GoPal Assistant)
-
-



1.1 Important information



For safety reasons, the driver must not make entries whilst driving. The instructions issued by the navigation system are recommendations. The road traffic regulations must be observed in all cases.



Thermally insulated glass or windscreens with metallic coating reduce the GPS reception a lot. Usually this type of coating is omitted at a special place behind which the navigation unit can be fitted. If that is not the case, a commercially available GPS aerial has to be fitted outside, e.g. on the roof of the vehicle.



1.2 Alternative installation of navigation software from a memory card

The software for your navigation system can also be directly installed from an appropriately prepared memory card. Preinstalled software may have to be de-installed first (see device manual).

On first-time set-up you will be requested to install the navigation software. Please proceed as follows:

- a. Carefully remove the memory card from the packaging. Please take care not to touch contacts or allow them to become soiled.
- b. Insert the memory card in the SD/MMC slot until it clicks into place.
- c. Click *OK* to install the application.

Once all data has been copied to your navigation system, the main window will be displayed in which you can now perform the navigation settings.

Note



Please take note that a valid GPS signal must be received and the time zone needs to be set after the installation of the software, so that the correct arrival time can be calculated in future route calculations.



1.3 Further map material

Your navigation system is already supplied ex works with a digitalised map of your country in its internal memory. Further digitalised maps may be added to those in the internal memory. Depending on the version, further digitalised maps will be featured on your DVD. These maps may be immediately transferred to a memory card whereby the use of an external card reader is recommended (see device manual).

Depending on the extent of the map material, memory cards with 256 MB, 512 MB, 1,024 MB or larger are required.

Note



Please note that some of the devices do not include memory cards in the delivery. In these units the installation and map files have already been loaded. The installation will run automatically.

Additional memory cards (MMC or SD cards) are stocked by specialist stores.



1.4 Transferring map material to a memory card

Transferring further map material to a memory card is best performed via your PC explorer. Please proceed as follows:

- a. Insert the DVD with the required map material.
- b. Open your workplace and select your DVD drive.
- c. Copy the file with the `.psf` extension from the directory of the region you require from the DVD to the directory `MapRegions` on your memory card.

You can transfer several files of map material to your memory card, depending on the size of the latter. Please hereby ensure that there is sufficient storage space on your memory card.

If you have copied digitalised maps of several countries or country groups to your memory card, you must select the required country map in the navigation application of your device.



1.5 Transferring installation files and map material to the internal memory

Your device features an internal, non-volatile memory Contained in the `\My Flash Disk` folder. Via ActiveSync® you can use the Search option to display this and further folders. Manipulations to folders and files can be performed as in an explorer.

The necessary folders must be created to make installation files and map material available to the device.

Create the `INSTALL` folder (`\My Flash Disk\INSTALL`) for the installation files. Store map material in the `MapRegions` (`\My Flash Disk\MapRegions`) folder. On naming folders please observe the writing forms specified above.

Should additional data be stored on your navigation device, please note that sufficient capacity must be available on transferring data. If this is not the case, remove files that are not required.

Note



The navigation system must be linked to the computer via ActiveSync® (see device manual) for data transfer.



1.6 Data transfer (GoPal Assistant)

The *GoPal Assistant* is available for transferring installation files and card data to the navigation device. In this case, use a memory card reading device or ActiveSync® connection.

Transferring the installation files

Note



Please note that the memory card is formatted before the data transfer! Please therefore ensure beforehand that there are no important files still on your memory card!

Before installing the software you must transfer the installation files using the *GoPal Assistant* as follows:

- a. The software will start up automatically when you insert the DVD into your PC drive. If the software does not start automatically, you can also run it directly from the DVD in Windows Explorer by clicking on the *GoPalAssistant.exe* file (directory: Assistant).
- b. Insert your memory card in the card reader or connect the navigation device via ActiveSync® to your PC.
- c. Select the drive for your memory card or drive linking ActiveSync® to your computer.
- d. You can now transfer the navigation software installation files from the DVD to your memory card by clicking on *Transfer software*.

Note



Please note that software installation in the navigation system is only performed following a hard reset (see: device manual).

Transferring the map data

Once the installation files have been transferred to your memory card you can create your own personal map area using a general map. Later on you can adapt your personal map area using the *GoPal Assistant*, i.e. delete map regions you no longer need or add new map regions.

- a. The software will start up automatically when you insert the DVD into your PC drive. If the software does not start automatically, you can also run it directly from the DVD in Windows Explorer by clicking on the *GoPalAssistant.exe* file (directory: Assistant).
- b. Insert your memory card in the card reader or connect the navigation device via ActiveSync® to your PC.
- c. Select the drive for your memory card or drive linking ActiveSync® to your computer.
- d. You can now switch to the general map by clicking on *Transfer Map Data*. There you can create your personal map area by clicking on the map regions. Simply follow the instructions in the software.

Note



If you have just transferred the navigation software installation files to your memory card, you will be back in your memory card drive view. You can switch directly to the general map by clicking on *Transfer Map Data*.

2. Operating the navigation software

This chapter contains information about the following subjects:

- 2.1 Symbols
 - 2.2 Map
 - 2.3 Destination
 - 2.4 Route
 - 2.5 View
 - 2.6 Settings
-
-



2.1 Symbols

Symbols in menus



Use this symbol to access the menu bar.



Use this symbol to access the *View* menu.



Use this symbol to access the *Destination* menu.



Use this symbol to access the *Route* menu.



Use this symbol to access the *Settings* menu.



Use this symbol to access the *Help* menu.



Use this symbol to access the previous screen.



Use this symbol to confirm the entry and move to the next screen.



Use this symbol to exit the navigation software.

Symbols on map



Press this symbol to access the compass.



This symbol displays the battery status of the device.



Use this symbol to check GPS signal quality and by clicking on the symbol you can change to *Compass* view.



Current traffic information can be received via the TMC module, which will then be displayed on the map with a corresponding traffic symbol.



The green TMCpro symbol shows whether TMCpro can be decoded.



If a red TMCpro symbol shows, no TMCpro data can be decoded.



A warning symbol on the map as well as an acoustic warning will alert you to the nearest traffic hold-ups on your route that affect your travelling time.



Clicking on the warning symbol will take you to the traffic warning view.



If the traffic hold-ups are not along the precalculated route, the symbols are shown in grey.



Telephone function (only with Bluetooth handsets)




The current speed limit is shown on the map for certain route sections.

2.2 Map

The map view contains the following information:



Resolution: 320 x 240 pixels



Resolution: 480 x 272 pixels

1	Compass	8	Your current position
2	Road you are currently travelling on ¹	9	Main menu/Autozoom ²
3	TMC reception quality	10	Estimated arrival time
4	Display of the battery status	11	Remaining time to travel
5	GPS reception quality	12	Remaining distance to the destination
6	Scale	13	View
7	Zoom		

¹) When carrying out a manoeuvre additional distance and turning information are shown. The turning information can also point out the lane to be used, if this information is available in the map data.

²) After zooming in or out, you can use this switch to reactivate Autozoom.



By pressing the touch screen with a finger or pen you can move the map freely.

You can select a destination directly from the map. Touch the area of the map that you want to go to. If your desired destination is not in the area touched, you can use the menu bar at the bottom of the screen to switch to further areas nearby.



Use this to navigate to the previously marked section of the map.



Use this to navigate to the next marked section of the map.



Use this to select the marked area as your destination.




2.3 Destination


After starting the navigation software you can plan your route and drive off immediately after entering the destination.



2.3.1 Enter new destination



Resolution: 320 x 240 pixels



Resolution: 480 x 272 pixels

- | | | | |
|----------|---|----------|--|
| 1 | Select one of the last chosen destinations | 4 | Enter the postcode |
| 2 | Selecting a search category (roads or special places) | 5 | Enter street name or house number |
| 3 | Enter town or select country | 6 | Select a destination from the favourites |

¹⁾ When you have selected a special place (e.g. hotel) under search category, the input boxes *Street* and *House number* are replaced by the input box *Name*.

Note



You can search for a place using the postcode and/or the town/city. In order to further specify the search you can enter the street and house number. If it is possible to take the house number into consideration when calculating the route, this will be indicated in the *Detailed information* view. You can also reach the town centre without giving a street name, or reach the middle of a street without giving a house number.

When searching for a special place (e.g. a petrol station), entering the name will allow a more detailed search.

Use the keyboard to enter your destination address. The navigation software automatically completes the address when searching for a destination. After entering just a few characters, you will be shown the three best results along with the list of all possible results. If the place you are looking for does not appear on the list, you may have to enter more detailed information for the address.



2.3.2 Search for

You can use the search category to determine the type of destination. By default, the program will search for the road/street of the entered address. But you can also select a different category and search for special places such as hotels, airports or petrol stations in a certain town.

If you own a device with a Bluetooth function and have the telephone number of your selected destination, you can dial this number using the *Detailed information* screen.



2.3.3 Favourites

This is a list containing those destinations you have saved and that you require more frequently.



2.3.4 Last locations

The last used destination locations are saved in chronological sequence and can be reactivated as destination using this option. The last three can be selected directly from the address field, all other previous locations can be accessed via *Last locations*.



2.3.5 Route options

Before calculating the route you can determine the route options in the detailed information of the destination. You can use the route options to determine the way you are guided to your destination.



Route calculation and guide optimised for motor vehicles (standard option)



Route calculation and guide optimised for cyclists (possible up to a radius of 50 km)



Route calculation and guide optimised for pedestrians (possible up to a radius of 50 km)



Route calculation and route guiding optimised for motorcyclists



The optimisation of the calculated route is based on the time factor (standard option).



The optimisation of the calculated route is based on the length of the journey.



Economic route: a combination of short and fast route



Toll roads are included in the route calculation (standard option).



Toll roads are avoided in the route calculation.



Motorways are included in the route calculation (standard option).



Motorways are avoided in the route calculation.



Ferries are included in the route calculation (standard option).



Ferries are avoided in the route calculation.



No congestion by-pass



Manual congestion by-pass



Automatic congestion by-pass



2.3.6 Add location to favourites

You can choose this option in the detailed information in order to save the displayed location in the favourites.



2.3.7 Show location

You can use this option to have the location displayed in the map beforehand.



2.3.8 Calculating the route

Once you have checked the destination details and selected the route options according to your preferences, you can start the route calculation. The calculation can only be done when the unit works without any faults. Faults are identified as follows:



The GPS reception is faulty. Your current location can therefore not be determined.



2.3.9 Quick search

Using the quick search you can look for items in a pre-set search category (e.g.: hotels, airports or petrol stations).



2.3.10 Area search

You will be offered special places near your current location for your selection. For the identified places, the device will also display the distance as the crow flies.

Note



At first, the navigation software will search within a smaller radius. If this does not yield any results, the search is extended to a larger radius. This may cause a time delay in certain circumstances.



2.3.11 Route planning

Using this option you can plan a route (e.g. the day before going on holiday) by entering the starting point and destination, even while the GPS receiver is switched off. You can also enter multiple destinations, which are navigated one after the other.



Your starting point (as standard, the last known position is used)



You can add up to 5 destinations.



Move the selected destination upwards.



Move the selected destination downwards.



Delete a destination.



The starting point of the route can be changed here.



Using this function the route can be optimised for the whole journey.



After planning the route you can call up the planned route in the map view using the function *Start routing*. For this purpose, the GPS receiver needs to receive a signal.



2.3.12 Save current position

You can use this function to save your current position as favourite. However this will only work if you receive a GPS signal with your navigation device.



2.3.13 Stored locations

Using the *Stored locations* function you can rename or delete your personal favourites, or delete the last destination visited or all previous destinations.



2.4 Route

Once the route has been calculated successfully, you will be guided to the specified destination with the help of acoustic and visual instructions.

The following functions can be used during navigation:



2.4.1 Go to ...

When navigating or after planning a route you can change your view here to see an overview of your route or your destination area or return to your current location or, if planning a route, your starting point.



2.4.2 Change route

You can change your current route as described in [Section 2.3.11, "Route planning"](#).



2.4.3 Directions

The description of the route tells you what roads to take in order to reach your destination. In addition, border crossings into other countries are marked. The route description is only available once you have calculated a route.



2.4.4 Route options

You can also change your route options during navigation in order to influence the way that you reach your destination (see [Section 2.3.11, "Route planning"](#)).



2.4.5 Stop route guide

Use this function to terminate the current routing and delete the route from the memory.



2.5 View

You can switch between various views when navigating:




2.5.1 2-D or 3-D map

Here you can change quickly between a 2-D and 3-D view of the map.




2.5.2 Turn icon view

The turn icon view contains the following information:



Resolution: 320 x 240 pixels



Resolution: 480 x 272 pixels

- | | | | |
|----------|--------------------------------------|-----------|--|
| 1 | Next manoeuvre | 7 | Preview of next manoeuvre |
| 2 | Road you are currently travelling on | 8 | Use this symbol to access the previous screen. |
| 3 | TMC reception quality | 9 | Estimated arrival time |
| 4 | Display of the battery status | 10 | Remaining time to travel |
| 5 | GPS reception quality | 11 | Remaining distance to the destination |
| 6 | Distance to the next manoeuvre | | |



2.5.3 Traffic Situation

You can use this function to have current traffic information displayed in a list. This will show first the traffic reports affecting your route (sorted by distance) and then the events not situated along your route (in alphabetical order).



If you select an entry from the list, the detailed view of this traffic update will appear. If this traffic disruption is on your route the detailed view will indicate how far away it is. If the traffic disruption will affect your journey time (congestion, slow-moving traffic) the detailed view will also indicate the estimated time lost.



If the traffic hold-ups are not along the precalculated route, the symbols are shown in grey.

In the traffic warning view you will be shown the distance to the traffic hold-up affecting your route and the likely delay in travelling time and you will be given the option to ask for an alternative route to be calculated.

If you don't want to ask for a calculation of an alternative route you can decline and the warning symbol will disappear from the map.

If you want to ask for an alternative route to be calculated, the navigation software will calculate a route which tries to bypass the traffic hold-up.

If it is not possible to calculate an alternative route, the warning will disappear from the map, but you can select the traffic hold-up affecting your route once again in the list view and then ask again for an alternative route to be calculated in the traffic warning view.

Note



In Germany, TMCpro information can be received in addition to TMC information (see [Section 2.6.8, "TMCpro search"](#)). In the list view as well as detailed view traffic news is marked with an extra symbol.



2.5.4 Compass

In the compass you can read the speed, the current longitude and latitude as well as the GPS reception quality (HDOP value). The direction of travel is displayed reliably from a speed of approximately 3 mph.

In addition, after a GPS signal has been received once the GPS time will be displayed in Greenwich Mean Time (GMT).



2.5.5 Journey info

In this option you can view information on your current route, such as average speed, total journey time elapsed or total distance covered.



2.5.6 Other Applications

If your navigation system has other applications, these can be started directly from the navigation software.



2.6 Settings

It is possible to configure the navigation software individually using a number of setting options.



2.6.1 Settings for the unit

The following settings can be adjusted on your unit:



Here you can view the charging status of the device's battery and whether the device is charging at present. Furthermore, to save electricity you can select times for mains or battery operation, after which the device is switched off.



In this settings template you can re-calibrate the touch screen when this does not react accurately to the touch. For calibration, a cross appears in the middle of the screen. After pressing this cross it will move on across the screen. Keep pressing the cross until it is back in the centre of the screen. By pressing the touch screen again, the calibrated setting will be adopted. If you do not confirm the calibration, the view will be quit after a pre-selected period without changes.



Here you can set whether MP3 track titles are displayed in the navigation software while they are playing.



Use this to adjust the sound volume of your unit (e.g.: key clicks).



This can be used to adjust the brightness of the screen.



Using this function you can reset your device to the factory settings. By doing so all personal settings will be deleted.



Telephone function (only with Bluetooth handsets)



2.6.2 Display

You have the following options for the display:



The map is displayed in north orientation or in the direction of travel, depending on the scale of the map (2D-map view).



The map always turns according to the direction of travel (2D-map view).



The map is displayed in north orientation (2D-map view).



The 3D map is always displayed in the direction of travel. The zoom function remains active in the 3D map, but it is no longer possible to move the map.



Display of the map view with daylight optimised design.



Display of the map view with darkness optimised design.



The design of the map is adjusted to daylight or darkness, depending on the time of day.



During the manoeuvre the map changes automatically into arrow view. After the manoeuvre the display changes back to map view.



Map view remains on display also during a manoeuvre. A small version of the manoeuvre arrow appears on the map.



2.6.3 Volume control

Use this to adjust the sound volume of the acoustic instructions issued by the navigation software. Adjust the system volume in the settings of the device under *Settings*.



2.6.4 Language

If your navigation device has several languages installed, you can use this to select another language. After the selection, the device reboots and uses the language selected by you.



2.6.5 Map selection

If you have installed more than one map area on your memory card, you can select an area here.



2.6.6 Advarsel om max. hastighed

You can use this function to receive an acoustic warning during your journey when you go over the speed limit. This is also displayed on the map with a symbol.

You can set the acoustic warning to go off when you exceed the speed limit by 5, 10, 15, 20, 25, 30 km/h or mph.

Show without warning: Only the speed limits are shown on the map here; there is no acoustic warning when you exceed the speed limit.

Do not show: You can deactivate the speed limit warning here.



2.6.7 Search for TMC stations.



Here a station is searched for automatically. If reception quality deteriorates a new station is immediately searched for.



Using manual station search you can permanently set a TMC station. If the TMC signal deteriorates, a new station is not automatically searched for.



Here you can search for a TMC station in 100 KHz increments.



2.6.8 TMCpro search

Here you can set whether you wish to receive TMCpro traffic news.

Note



TMC uses data supplied by the police, traffic jam reports, the ADAC (German AA) or other human sources. Unlike TMC, TMCpro accesses automatic data sensors on motorway bridges, sensors integrated into the carriageway and cars with Floating Car Data (FCD) technology.



TMCpro use (no TMC)



Simultaneous use of TMC and TMCpro (TMCpro traffic information is marked)



TMC use (no TMCpro)



2.6.9 Congestion by-pass



You can specify in this view whether or not you want to be automatically directed away from congestion. The navigation software will then automatically inform you in the background using the traffic information available of alternative routes away from any traffic disruptions on your route that will affect your journey time.



With manual congestion by-pass a warning symbol in the map view will alert you to the nearest traffic disruption on your route that will affect your journey time.



Clicking on the warning symbol will take you to the traffic warning view where you can select whether or not an alternative route is to be calculated.



If you selected *No congestion by-pass* the latest traffic updates will not be taken into account in the route guidance.



2.6.10 Preferred petrol stations

Enter your preferred brands of petrol here. This is particularly useful if you have a loyalty card for a particular brand of petrol and want this brand of petrol station to be shown first when searching for one.



2.6.11 Quick search category

Here you can determine search categories in the quick search for a specific place (e.g. a petrol station).



2.6.12 Info

This contains information about the software and map versions.

3. Further notes

This chapter contains information about the following subjects:

[3.1 Liability](#)

[3.2 Trademarks](#)



3.1 Liability

The software and the manual are subject to change without notice. MEDION AG may not be liable for the correctness of the information contained in this manual nor for damages resulting from the use of this manual.

To improve the quality of our products and our services, we appreciate all suggestions or improvement and all error notices.



3.2 Trademarks

All brands and trademarks mentioned in this document are possibly registered by third party and subject to the current legislation and to the rights of their respective owners without reservation. All mentioned names of products, societies, or brands may be registered trademarks of their respective owners. Every right that is not explicitly accorded is reserved.

The absence of an explicit labelling of registered trademarks does not allow the conclusion that this brand was not subject to the rights of third party.

Windows[®] and ActiveSync[®] are registered trademarks of the Microsoft[®] Corporation.